



## Manufacturer Recommended Spray Booth Maintenance Schedule

Spray Booth Maintenance	Daily	Weekly	Quarterly	Semi-Annual	Annual	As Required
Clean / wipe down air hoses	●					
Vacuum interior of spray booth		●				
Wipe interior of spray booth walls		●				
Replace Exhaust Filters		●				
Clean light fixture glass			●			
Vacuum pit and tunnel / towers			●			
Clean and remove overspray from floor			●			
Check motor belts			●			
Clean/Pressure Wash floor grates (Outside of Booth)			●			
Inspect door seals (replace when required)			●			
Check and tighten all electrical connections			●			
Service airflow switches / clean and adjust			●			
Lubricate door hinges				●		
Lubricate blower shaft bearings				●		
Calibrate booth pressure balancing gauge				●		
Fire suppression system				●		
Clean light tubes					●	
Check light fixture glass seals					●	
Clean inside of all light fixtures and glass					●	
Clean exhaust stack, dampers and stackhead					●	
Clean main exhaust blower / fan					●	
Burner system tune-up (start-up procedure) / cleaning					●	
Clean upper plenum					●	
Lubricate motors					●	
Check Air Balance					●	
Replace Intake Filters					●	
Check/Adjust Compressed Air System					●	
Bulbs – Check and Replace						●
Door seal / gasket replacement						●
Door hinge brass bushing replacement						●



## **Manufacturer Recommended Spray Booth Maintenance Schedule**